

RO-MAN

WASTE CLAMP



SELECT A LOCATION FOR THE DRAIN HOLE BASED ON THE DESIGN OF THE PLUMBING. POSITION THE DRAIN OUTLET SADDLE ON THE DRAINPIPE. ALLOW ADEQUATE SPACE FOR DRILLING. TIGHTEN THE BOLTS EVENLY ON BOTH SIDES. AVOID OVER TIGHTENING.

USING THE OPENING IN THE DRAIN OUTLET SADDLE AS A GUIDE, DRILL A 1/4" HOLE IN THE DRAIN PIPE. CLEAN DEBRIS FROM THE SADDLE AND THREADS